

1. Project example modularized machine platform based on the Z-110 series (rotary system) as closing machine for consumer health and/or cosmetic containers



Customer requirements

Containers: Various cosmetic containers up to a height of 200 mm and a diameter of 90 mm, expandable to

airless and dispenser closures

Process: Gentle cap infeed (no scratching of sensitive caps), torque control, in process control

(presence and position of the cap) with automatic ejection, screwing/crimping

Output 45 containers/min (80 containers for a double-step machine)

Our solution: Automatic closing machine Z-110 k

Features

- Cap infeed by means of an inclined table, optional alternatives:
 - vibrating bowl
 - belt band (for caps and sprays)
 - turntable
- Servomotoric pre- and post-screwing axis with snap-on function, 3-jaw gripper and vacuum based cap holding.
 Suitable for a variety of closures.
- Vacuum based container holding instead of clamping (no scratching)
- In process control: torque, rotation angle and position control by the screwing axes. Cross control with sensors: no cap in place or cap too high/inclined with automatic ejection of non-conform containers
- Easy format change without tools: Gripper jaws clicked in, lateral guidance of cap conveyor and pick nest can be adapted by means of setting knobs with digital counters, wing handles



1. Project example modularized machine platform based on the Z-110 series (rotary system) as closing machine for consumer health and/or cosmetic containers



Figure 1: Machine overview



Figure 2: Setting knobs





Figure 4: Wing handle

Customer benefits

- Fully automatic process run in compact monobloc design
- Modular cap infeed options dependant on the cap type
- Snap-on and screw-on caps on the same machine
- Vacuum holding of containers and caps, suitable for sensitive products (no scratching)
- Pre- and postscrewing unit for an increased and optimal output
- Tool-free format part change according to the poka joke-principle (Japanese, engl. «avoid unfortunate errors»)
- Format parts are avoided whereever possible
- Indexed and reproducible settings



2. Test laboratory

We have established a test laboratory that we expand continuously to offer our customers an optimal feasibility service in advance of a project by executing, documenting and analysing "proof of principle" testing.

Here we can carry out e.g. the following tests:

- Filling test of liquids, semi solids (creams, balms) and solids with different dosing systems:
 - rotary piston
 - peristaltic pump
 - endless pistion
 - gear pump
 - turn piston pump
 - rotatory pistion pump
- Filling under vacuum
- Closing tests (snap-on, press-on, screw-on)
- Determination of the torque during closing
- Determination of the snap-on force
- Determination of the optimal screwing unit will a pneumatic screwing unit be sufficient or will an electric one be needed?
- Material selection for optimal sliding properties of your container type

Examples for tests:

- Dosing of micro pearls (cosmetics): check accuracy / shear at the product
- Dosing of hyaluronic acid in syringes under vacuum: check accuracy and air bubbles
- Dosing of permanent make up in small bottles: accuracy / cleaning
- Snap-on tests with airless containers on the Z-201 S platform
- Dosing of propolis products with high solids content (wax) with rotary piston: accuracy / product build up that blocks the piston



3. We expose on the following fairs



PACK EXPO INTERNATIONAL, 06. - 09. November 2016, Chicago Illinois, USA Visit us at booth # E-8309. We are looking forward to seeing you!



Compamed, 14. - 17. November 2016, Düsseldorf, Germany Visit us in hall 8a at booth K16. We are looking forward to seeing you!



pharmtech & ingredients, 22. - 25. November 2016, Moskow, Russia Visit us at the Crocus Expo IEC, pavillion 2 at the booth of P.E.C. We are looking forward to seeing you!



Pharmapack, 01. - 02. February 2017, Paris, France Visit us at the Paris expo Porte de Versaille, hall 4, at booth F49. We are looking forward to seeing you!